DO45 Tow Hitch

Chassis · https://wonderlandrv.com.au/manuals/do45/

Warranty Period:

3 Years

Warranty Link:

View Warranty

Manual Link:

View Manual

Maintenance Details:

1. Keep the Tow Pin and Universal mating surfaces clean and lightly greased at all times.
2. Check the condition of Tow Pin O-Ring and replace if necessary.
3. Regularly lubricate grease points with multi-purpose lithium grease.
4. Periodic adjustment of the Slotted Nut & Pin may be required if coupling head loosens excessively and should be completed by a competent person.
5. Flush with clean water or air hose if locking mechanism does not open fully due to dirt ingress.

Troubleshooting Guide:

N/A